

INTERLAB

Tel: +331 3971 7337 – Fax: +331 3928 9008

ISSUE: Access to Debug commands

Concerned platforms:

LIGHTWORKS MR, MR+, Touch & Softworks

Vernouillet, 10.11.2006

ISSUE & SITUATION:

To have the ability to turn on or off certain specific features not directly accessible via the standard user interface, you can access them via the key mapping (fingerprint)

Slowmo File interlacing command: (disabling)

The half line shift we apply makes the user interface viewers steady during slow motion, but affects the video output. Here's how to turn it off, if you do this you will see 'bopping' on the viewers during slow motion but I think the video output will be improved.

SOLLUTION:

To activate this feature:

1. Quit the Lightworks application and start the registry editor (regedit)
2. goto HKEY_LOCAL_MACHINE\SOFTWARE\Lightworks\Configuration
3. Add a new string value (select Edit->New->String Value) which has name: 'Show Debug Commands' data: 'true'
4. restart the application and enter a room
5. Goto user preferences->Change/view key assignment (fingerprint button, top right)
6. in the 'Key assignments' list you should now see many commands in square brackets. Double click on '_Toggle_CompensateForRasterContradiction'
7. assign a key (e.g. select Alt-r, then hit 'Add Key')
8. You can now toggle the half-line shift on/off by hitting your selected key. You will see a message on the status window (cfgCompensateForRasterContradiction is now ON/OFF) when this happens..

Pls. send us your feel back.

Rev.0 – David 25.01.06